



2/27





**|** 


3/27




+







7/27



 $\vdash$ 

FIG. 8A




FIG. 8B






FIG. 9





#### FIG. 11A






FIG. 11B





13/27







FIG. 14A

COPYING CAN BE EXECUTED.								
100% AUTOMATIC SHEET FEED 1								
NON- MAGNIFICATION	MAGNIFICATION •							
SHEET SELECTION		LIGHT AUTO DARK						
		CHARACTER -						
SORTER	DOUBLE-SIDED	APPLIED MODE						

FIG. 14B

SELECTION OF SORTER TYPE						
SORTING	ROUP					
BOOKBINDING						
SHIFT	Z-FOLDING					
CANCEL	OK					

FIG. 14C



## FIG. 15C

FIG. 15C	SELECTION OF MAINTENANCE ITEM FOR FOLDER	STOPPER POSITION ADJUSTMENT	FOLDING; ROLLER; PRESSURE CONTACT: FORCE: ADJUSTMENT		RETURN OK	
FIG. 15A	SELECTION OF SECTION FOR MAINTENANCE	PRINTER	READER	AUTOMATIC SHEET FEEDER	RETURN OK	

(RANGE) (1-20)	OK	
SETTING VALUE		
FOLDING ROLLER PRESSURE CONTACT FORCE ADJUSTMENT	RETURN	


70.10	SELECTION OF MAINTENANCE ITEM FOR FOLDER	ADJUSTMENT	CLEANING	COMPONENT REPLACEMENT	OK	
-------	---	------------	----------	-----------------------	----	--

### **EXECUTE AFTER COMPLETION OF JOB** SWITCH TO MAIN SCREEN IT IS NECESSARY TO EXECUTE ADJUSTMENT ON OOO **EXECUTE IMMEDIATELY** FIG. 16C SWITCH TO MAIN SCREEN MAINTENANCE (ADJUSTMENT BEING EXECUTED) ... PLEASE WAIT FOR A WHILE ... FIG. 16A ABORT

# SUB-MAINTENANCE ADJUSTMENT FOLDING ROLLER PRESSURE CONTACT FORCE ADJUSTMENT FORCE ADJUSTMENT TOR (1-20)

MAINTENANCE (REPLACEMENT BEING EXECUTED)	CEMENT IS	COMPLETION ABORT SWITCH TO MAIN SCREEN	

FIG. 16B




## FIG.~I8A

		18/2	27				
SUB-MAINTENANCE ITEM 2	2ND FOLDING POSITION ADJUSTMENT		2ND FOLDING POSITION ADJUSTMENT				
SUB-MAINTENANCE ITEM 1	FOLDING ROLLER PRESSURE CONTACT FORCE ADJUSTMENT 1ST FOLDING POSITION ADJUSTMENT		1ST FOLDING POSITION ADJUSTMENT	2ND FOLDING POSITION ADJUSTMENT	FOLDER CONVEYING SENSOR 1 LIGHT AMOUNT ADJUSTMENT	FOLDER CONVEYING SENSOR 2 LIGHT AMOUNT ADJUSTMENT	
MAINTENANCE ITEM	FOLDING ROLLER REPLACEMENT	FOLDER CONVEYING ROLLER REPLACEMENT	REPLACEMENT 1ST FOLDING STOPPER REPLACEMENT	2ND FOLDING STOPPER REPLACEMENT	FOLDER CONVEYING SENSOR 1 REPLACEMENT	FOLDER CONVEYING SENSOR 2 REPLACEMENT	
ITEM	REPLACEMENT	REPLACEMENT	REPLACEMENT	REPLACEMENT	REPLACEMENT	REPLACEMENT	
MODULE NAME	FOLDER	FOLDER	FOLDER	FOLDER	FOLDER	FOLDER	


## FIG.~18B

			-	19/2	7					
			2ND FOLDING POSITION ADJUSTMENT						FOLDER CONVEYING SENSOR 1 LIGHT AMOUNT ADJUSTMENT	FOLDER CONVEYING SENSOR 2 LIGHT AMOUNT ADJUSTMENT
FOLDER CONVEYING SENSOR 1 LIGHT AMOUNT ADJUSTMENT	FOLDER CONVEYING SENSOR 2 LIGHT AMOUNT ADJUSTMENT	FOLDING ROLLER PRESSURE CONTACT FORCE ADJUSTMENT	1ST FOLDING POSITION ADJUSTMENT	2ND FOLDING POSITION ADJUSTMENT	FOLDING ROLLER CLEANING	FOLDING CONVEYING ROLLER CLEANING	1ST FOLDING STOPPER CLEANING	2ND FOLDING STOPPER CLEANING	FOLDER CONVEYING SENSOR 1 CLEANING	FOLDER CONVEYING SENSOR 2 CLEANING
ADJIUSTMENT	ADJUSTMENT	ADJUSTMENT	ADJUSTMENT	ADJUSTMENT	CLEANING	CLEANING	CLIEANING	CLIEANING	CLEANING	CLEANING
FOLDER	FOLDER	FOLDER	FOLDER	FOLDER	FOLDER	FOLDER	FOLDER	FOLDER	FOLDER	FOLDER

FIG. 19




21/27






#### FIG. 20B



#### FIG. 21A



#### FIG. 21B




FIG. 22

